PREVIEW SCREEN

Tap the MAX button to show lyrics in full screen. When in full screen double tap to minimize

KEYCHANGE

Slightly adjusts key music key to help match the singers voice. Double tap the digital dial to reset

MASTER CONTROLS

Use the PLAY NEXT button to load next song.

Press the AUTOPLAY button for continuous play
through all of the songs on your playlist



SONG FINDER

Find songs to add to your playlist. Use the search box to input text and find particular artists or songs. Press the keypad icon to open the on screen keyboard. To add a song to your playlist double tap on it, add the singers name and press add

MULTIPLEX

Turn guide vocal on/off when playing multiplex karaoke tracks

PLAYLIST

Songs added from the Song Finder section will list here. Double tap a song to show options such as move up/down, change singer name, play now or remove. Playlist duration of chosen songs will show in the corner, hit the clear button to wipe your playlist